

## INSTALLATION INSTRUCTIONS K9-A-123 OPTIONAL DIVIDER FOR K9-D25 INSERT

### TOOLS REQUIRED:

Phillips screwdriver                      7/16" open end wrench                      Awl tool

### HARDWARE and PARTS:

QTY	DESCRIPTION	PART#
6	1/4" Serrated flange nut	GSM30170
6	1/4" X 3/4" Carriage bolt	GSM32024

### INSTALLATION:

1. Install main K9 insert.
2. Place divider wall assembly inside K9 insert with swing door towards the front.
3. Use Awl or Phillips screwdriver to align four (4) mounting holes.
4. Attach divider to front and rear bulkhead with 1/4" X 3/4" Carriage bolts and nuts.
5. Tighten hardware and check emergency exit door operation.
6. Cut rubber mat if desired, on either side of divider.



K9-A-123-B