Havis, Inc.
75 Jacksonville Road
Warminster, PA 18974
T 800-524-9900 F 215-957-0729
www.havis.com

INSTALLATION INSTRUCTIONS K9-A-D25-DIV
OPTIONAL DIVIDER FOR K9-D25 INSERT

TOOLS REQUIRED:

7/16” open end wrench Awl tool

HARDWARE and PARTS:

QTY	DESCRIPTION	PART#
6	1/4" Serrated flange nut	GSM30170
6	1/4" X 3/4" Carriage bolt	GSM32024

INSTALLATION:

1. Install main K9 insert.
2. Place divider wall assembly inside K9 insert with swing door towards the front.
3. Use Awl to align the mounting holes.
4. Attach divider to front and rear bulkhead with 1/4" X 3/4" Carriage bolts and nuts.
5. Tighten hardware and check emergency exit door operation.
6. Cut rubber mat if desired, on either side of divider.



K9-A-D25-DIV-B