



ITEM NO.	QTY.	HK	PART NUMBER	DESCRIPTION	Revision
1	2		CM002267	BRACKET, LATCH, UNIVERSAL MOUNTING	C
2	2		CM002400	BRACKET, MOUNT, 45° 3.5" LOWER OFFSET BASE W/SLOTS	H
3	2		CM002624	EXTRUSION SPIDER, 2PC, COLLAR	A1
4	1		CM005197	BRACKET, BASE, HDM, FORD ESCAPE, 2013	A
5	4		GSM30005	NUT 1/4-20 HEX BLK, ZINC, GRD 5	
6	8		GSM30007	NUT 5/16-18 HEX ZP	
7	1		GSM30023	NUT 1/4-20 HEX FLANGE SERRATED ZP, BLK	
8	6		GSM31005	WASHER, 1/4 FLAT ZP, BLACK	
9	17		GSM31006	WASHER, 5/16" FLAT, SAE ZP	
10	4		GSM31026	WASHER 1/4 LOCK ZP BLK	
11	9		GSM31027	WASHER, 5/16" LOCK, ZP	
12	1		GSM33000	SCREW 1/4-20 X 1/2 HHCS, BLK, ZP, GRD 5	
13	5		GSM33001	SCREW 1/4-20 x 3/4" HHCS ZP BLK	
14	1		GSM33011	SCREW, 5/16-18 X 3/4"	
15	8		GSM33012	SCREW 5/16-18 X 1 HHCS ZP	
16	4		GSM34214	SHCS, STAINLESS 10-24 X 1-1/4" LG	-

INSTALLATION INSTRUCTIONS

1. REMOVE PASSENGER SIDE FRONT SEAT BOLTS.
2. SLIDE BASE (4) UNDER THE SEAT. ALIGN HOLES IN BASE WITH SEAT MOUNTING HOLES AND SEAT BRACKETS.
3. REINSTALL OEM SEAT BOLTS AND TIGHTEN TO VEHICLE MANUFACTURERS TORQUE SPECS.
4. ATTACH FIRST LOWER OFFSET (2) TO BASEPLATE WITH 5/16" BOLTS (15), LOCK WASHERS (11) AND FLAT WASHERS (9), ANGLE TOWARDS CENTER OF VEHICLE.
5. ATTACH SECOND LOWER OFFSET (2) TO FIRST LOWER OFFSET (2) WITH 5/16" BOLTS (15), LOCK WASHERS (11) AND FLAT WASHERS (9) ANGLE TOWARDS REAR OF VEHICLE.
6. INSTALL SPIDER COLLAR (3) ON THE HDM POLE (POLE NOT SHOWN) AS A SNUG FIT USING 10-24 SHCS (16).
7. FIX HDM POLE ONTO THE BASE BRACKET USING HARDWARE FROM C-HK-101 HARDWARE KIT.
8. INSTALL SUPPORT ARM TO COLLAR AS SHOWN USING 1/4-20 HARDWARE SUPPLIED (8) (10) (13), ATTACH UNDER DASH WITH "L" BRACKETS SUPPLIED.
9. REMOVE PLASTIC "PUSH IN" FASTENER AT LOWER FORWARD PASSENGER SIDE OF OEM CENTER CONSOLE. ATTACH "L" BRACKET (1) TO OEM FASTENER HOLE WITH 1/4-20 X 3/4" BOLT (13), WASHER (8) AND NUT (7) PROVIDED. NOTE THE TRICK TO GETTING THE NUT (7) ON THE INSIDE OF THE DASH IS TO USE TAPE ON YOUR FINGER TO HOLD THE NUT. PULL OUT PLASTIC SIDE PANEL ENOUGH TO GET YOUR HAND BEHIND. ATTACH BRACKET AND HARDWARE.
10. FOLLOW GENERAL INSTRUCTIONS FOR POLE AND UPPER MOUNT PARTS.

PROJECT #	REV.	DESCRIPTION
1918	9-15	RELEASED TO PRODUCTION
2243	10-15	CHANGED MOUNTING LOCATION OF SUPPORT ARM TO THE OEM DASH



HAVIS HAVIS, INC. 75 JACKSONVILLE RD.
WARMINSTER, PA. 18974
1-800-524-9900

TITLE: 2015+ FORD TRANSIT CONNECT

DO NOT SCALE DRAWING

SIZE	DWG. NO.	REV
A	C-HDM-189-INST	10-15
WEIGHT (LB): 12.713	SCALE: 1:8	SHEET 1 OF 1