



ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	2	10-003319	SPACER, 1"
2	1	10-004049	BRACKET, MOUNT, HDM BASE, DODGE RAM
3	4	GSM31006	WASHER, 5/16" FLAT, SAE ZP
4	4	GSM31027	WASHER, 5/16" LOCK, ZP
5	4	GSM33011	SCREW, 5/16-18 X 3/4"
6	4	GSM31018	WASHER 5/16 X 1 1/4 FENDER ZP
7	2	GSM33724	M8 X 1.25 X 55mm LG
8	1	CM002531	BRACKET, MOUNT, 55 DEG. 5" LOWER OFFSET BASE W/ SLOTS

INSTALLATION INSTRUCTIONS

1. REMOVE PASSENGER SIDE FRONT SEAT BOLTS.
2. PLACE SPACERS AND BASE OVER SEAT BRACKETS.
3. INSTALL SUPPLIED LONGER SEAT BOLTS AND WASHERS AND TIGHTEN TO VEHICLE MANUFACTURER'S TORQUE SPECIFICATION.
4. ATTACH LOWER OFFSET TO BASEPLATE WITH 5/16" BOLTS, LOCK WASHERS AND FLAT WASHERS ANGLE TOWARDS CENTER OF VEHICLE.
5. FOLLOW GENERAL INSTRUCTIONS FOR POLE AND UPPER MOUNT PARTS.

HAVIS HAVIS, INC.		75 JACKSONVILLE RD. WARMINSTER, PA. 18974 1-800-524-9900
TITLE: 07-18 DODGE RAM CAB CHASSIS HDM BASE		
DO NOT SCALE DRAWING		
SIZE A	DWG. NO. C-HDM-152-INST	REV 3-13
WEIGHT (LB): 8.13	SCALE: 1:4	SHEET 1 OF 1