

# INSTALLATION INSTRUCTIONS Vehicle Specific Console C-VSW-3000-F150-3 (30" inches of Equipment mounting space)

OR

## C-VSW-2400-F150-1 (24" inches of Equipment mounting space)

\* Either console does not work with 4 X 4 floor shifter or higher trim level trucks with full length center console\*

## For 2021-2024 for Ford F-150 Responder and SSV Pickup 2023-2024 Ford F-250, 350, 450 XL and XLT Super Duty pickup, F-450 & 550 cab chassis and F-600 Chassis Cab

#### **TOOLS REQUIRED:**

**Phillips Screw Driver** Standard Socket set T-20 Torx Bit Metric Socket set 7/16" Wrench **INSTALLATION PARTS AND MOUNTING HARDWARE:** QTY DESCRIPTION PART# 1 Ford small Aux panel adaptor 13071 1 Small Aux blank panel 13072 O-RING 1-9/16"ID X 1-3/4"OD X .093 16214 1 2 #8-18 X 3/8 PFHMS 16425 1/4" Hex nut kit 1 25520 (includes 12 nuts) 2 Speaker grill 23047 Parts already attached to console housing 1 Front floor mounting bracket 12884 1 Rear floor mounting bracket 12865 (C-VSW-3000-F150-3) 1 Rear floor mounting bracket 26086 (C-VSW-2400-F150-1) 1 Front console trim panel 38459 1 Forward corner pole knockout/AUX filler panel 12870 1 Electrical accessory mounting plate 12890

#### Notes:

## 1. Not all vehicles include an OEM 12 volt socket in front lower dash, but do include a Hook shaped plastic plug that can be relocated to new console instead.

### Always!

Read all instructions before installing any Havis, Inc. products.
Use hardware provided with install kit









Remove factory center seat or mini console



Unbolt factory bolts and save for later. 18mm socket



**NOTE:** Some vehicles include an OEM SmartLink / Telematics module mounted to transmission hump using the same bolts needed for the rear console bracket.

The OEM module must be unbolted and simply relocated under console by installer as desired. Relocating OEM module will not affect OEM system.



Place console with floor mount brackets into the vehicle. Shown with optional 3.3 wide panels and pocket.



Remove OEM AUX module and 12 volt socket from dash and save to be reused. See note 1 on page 1.



Slide console forward until the mounting brackets line up with the OEM mounting points in floor.





Loosely reinstall factory floor bolts through console floor brackets.



Main Housing installation is now complete. Install and wire equipment as desired.



Console installation complete. C-VSW-3000-F150-3 shown.



Install OEM AUX module into the console. Adaptor plate with #8 flat head screws provided for smaller Aux module. Blank plate provided if vehicle has no module for this location



Electrical accessory mounting plate shown. Unbolting and sliding console back for component installation is recommended.



Console with computer installation complete.