

INSTALLATION INSTRUCTIONS K9-A-108 OPTIONAL DIVIDER FOR K9-F28-XL INSERT

TOOLS REQUIRED:

Phillips screwdriver 7/16" open end wrench Awl tool

HARDWARE and PARTS:

QTY	DESCRIPTION	PART#
2	1/4" Serrated flange nut	GSM30170
2	1/4" Flat washer	GSM31048
2	1/4" X 3/4" Carriage bolt	GSM32024
2	1/4" X 3/4" Phillips head machine screw	GSM34102

INSTALLATION:

1. Install main K9 insert.
2. Place divider wall assembly inside K9 insert with swing door towards the front.
3. Use Awl or Phillips screwdriver to align four (4) mounting holes.
4. Attach divider to rear bulkhead with 1/4" X 3/4" Phillips screws and flat washers.
5. Attach divider to front bulkhead with 1/4" X 3/4" Carriage bolts and nuts.
6. Tighten hardware and check emergency exit door operation.
7. Cut rubber mat if desired, on either side of divider.



K9-A-108



K9-A-108-B