



#### INSTALLATION:

1. REMOVE OEM CONSOLE OR CENTER SEAT DEPENDING ON TRIM LEVEL EXPOSING THE "U" SHAPED MOUNTING BRACKETS.
2. REMOVE OEM "U" SHAPE FRONT AND REAR BRACKETS TO THE FLOOR / TRANS HUMP. RETAIN THE OEM HARDWARE
3. SOME VEHICLES INCLUDE AN OEM SMARTLINK/TELEMATICS MODULE MOUNTED TO TRANS HUMP USING THE SAME BOLTS NEEDED FOR THE CM007205 BRACKET. THE OEM MODULE MUST BE UNBOLTED AND RELOCATED UNDER OR BEHIND THE TRACK BY INSTALLER AS NEEDED. RELOCATING THE MODULE WILL NOT AFFECT OEM SYSTEM.
4. LOOSELY ATTACH CM007205 & CM007206 TO THE VEHICLE USING OEM HARDWARE. CM007205 GOES TOWARDS THE FRONT OF THE VEHICLE
5. LOOSELY ATTACH 1/4" X 1/2" HEX BOLTS AND HEX NUTS IN EACH SIDE HOLE OF FRONT BRACKET AND REAR BRACKET. (TWO EACH SIDE)
6. SLIDE TUNNEL PLATE ASSEMBLY FORWARD ONTO BOLTS /NUTS ON FRONT BRACKET.
7. POSITION TUNNEL PLATE AS DESIRED AND TIGHTEN HARDWARE
8. REMOVE BACKING FROM ADHESIVE STRIP AND INSTALL END CAP TO FRONT END OF TRACK.

1. **NOTE:** ADDITIONAL 1/4" HARDWARE PROVIDED TO ATTACH C-HDM-200 SERIES POLES TO C-TMW SERIES.
2. INSERT 1/4" HARDWARE FOR EQUIPMENT INTO TRAK CHANNEL BEFORE INSTALLING END CAPS.

ITEM NO.	QTY.	PART NUMBER	DESCRIPTION
1	12	GSM30005	NUT 1/4-20 HEX BLK, ZINC, GRD 5
2	4	GSM31005	WASHER, 1/4 FLAT ZP, BLACK
3	4	GSM31026	WASHER 1/4 LOCK ZP BLK
4	8	GSM31035	WASHER, 1/4 STAR EXT TOOTH ZP
5	8	GSM33000	SCREW 1/4-20 X 1/2 HHCS, BLK, ZP, GRD 5
6	4	GSM33001	SCREW 1/4-20 x 3/4" HHCS ZP BLK

**HAVIS** HAVIS, INC. 75 JACKSONVILLE RD.  
WARMINSTER, PA. 18974  
1-800-524-9900

TITLE:  
F-150 TUNNEL TRACK INSTALLATION

**DO NOT SCALE DRAWING**

SIZE	DWG. NO.	REV
<b>A</b>	C-TMW-F150-03_INST	1-20
WEIGHT (LB): 23.93	SCALE: 1:4	SHEET 1 OF 1