

INSTALLATION INSTRUCTIONS K9-A-D28-DIV OPTIONAL DIVIDER FOR K9-D28 INSERT

TOOLS REQUIRED:

7/16" open end wrench

Awl tool

HARDWARE and PARTS:

QTY	DESCRIPTION	PART#
6	1/4" Serrated flange nut	GSM30170
6	1/4" X 3/4" Carriage bolt	GSM32024

INSTALLATION:

1. Install main K9 insert.
2. Place divider wall assembly inside K9 insert with swing door towards the front.
3. Attach divider to front and rear bulkhead with 1/4" X 3/4" Carriage bolts and nuts.
4. Tighten hardware and check emergency exit door operation.
5. Cut rubber mat if desired, on either side of divider.



K9-A-D28-DIV-B