

INSTALLATION INSTRUCTIONS

C-DMM-3017 Flip up Dash Monitor Mount

2018 - 2023 Chevrolet Traverse

TOOLS REQUIRED:

- Ratchet Wrench
- Socket Set
- 7/16" Open End Wrench
- Phillips Screwdriver (short)
- Dash panel removal tool
- Wire strippers/cutters

PARTS and MOUNTING HARDWARE:

<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART#</u>
1	PS Upper mounting bracket	CM010632
1	DS Upper mounting bracket	CM010633
1	PS Lower mounting bracket	CM010813
1	DS Lower mounting bracket	CM010812
1	VESA swivel adaptor	CM010471
1	PVC spacer	CM010648
2	1/4" Nylon washer	CM86600
2	1/4" Nylock nut	GSM30016-1
2	1/4" Flat washer	GSM31005
6	#10 Flat washer	GSM31318
2	1/4" x 3/4" Carriage bolt	GSM32000
6	10-32 x 3/8" Machine screw	GSM33117


Notes:

1. The C-DMM-3000 swivel plate accepts C-MM-301 offset bracket used with C-MM-2XX adaptors.
2. C-MM-2XX series adaptor brackets are not needed for most VESA 75 and other Havis Docking Station mounting applications.
3. CM010471 VESA rotator plate gives additional positioning options, but is not required depending on mounting preference

Always!

- Read all instructions before installing any Havis, Inc. products.
- **Check for obstructions (Wires, brake lines, fuel tank, etc.) before drilling any holes!**
- Use hardware provided with install kit

C-DMM-3017
Assembly






View of Traverse dash prior to install.



Carefully pry along sides of trim with a panel removal tool.



Unplug hazard switch and remove trim.



Unclip and pull back trim around push to start.
This does not need to be fully removed.



Unclip and pull back trim on passenger side.
This does not need to be fully removed.



Remove OEM fastener and attach passenger side lower mounting bracket.
7mm socket



Remove OEM fastener and attach driver side lower mounting bracket.

7mm socket



Remove OEM fastener and attach driver side upper mounting bracket.

7mm socket



Remove OEM fastener and attach passenger side upper mounting bracket.

7mm socket



Plug in hazard switch and place trim back onto dash.



Note: Carefully snap trim back in making sure not to scratch against upper mounting brackets.



View of lower mounting bracket with trim fully snapped back in.



Place DMM frame onto mounting brackets and attach using 10-32 x 3/8" machine screw and flat washer.



Repeat for bottom mounting brackets.



Determine desired position for your specific computer and attach to DMM swivel plate using 1/4"x 3/4" carriage bolts, PVC spacer, nylon washers, steel washers, and nylock nuts. Tighten so that the dock rotates smoothly.



Confirm correct placement of dock and make sure rotation movement is smooth and latching works correctly.



Route wiring as needed.



Installation is now complete.